



**Sign fixing instructions using anti-rotational clips :**

1. Insert the "tang" end of the anti-rotational clip into the upper sign channel.
2. Slide the square headed bolt into the sign channel on the opposite side of the post.
3. Pass the anti-rotational clip around the post and over the bolt.
4. Add the washer and nut. Tighten slightly.
5. Repeat all the above with the lower sign channel.
6. Centre the sign to final position and fully tighten both clips.